

Pforten System Classic (typische Abmessungen)

Ausführung	Breite zwischen den Pfosten x Flügelhöhe (So x H) in [mm]				
	1000x1200	1000x1450	1000x1750	1200x1450	1200x1750
C 1001/P	✓	✓	✓	✓	✓
C 1002/P	✓	✓	✓	✓	✓
C 1004/P	✓	✓	✓	✓	✓
C 1005/P	✓	✓	✓	✓	✓
C 1006/P	✓	✓	✓	✓	✓
C 1016/P	✓	✓	✓	✓	✓
C 1017/P	✓	✓	✓	✓	✓
C VA55/P	✓	✓	✓	✓	✓
C 1070/P	✓	✓	-	✓	-
C 1071/P	✓	✓	-	✓	-
C 1072/P	✓	✓	-	✓	-
C 10TT/P	✓	✓	✓	✓	✓

P - gerade Ausführung des oberen Randes

Pforten System Classic (Sonderabmessungen)

Flügelhö- he (H) in [mm]	Abstand (Breite) zwischen den Pfosten (So) in [mm]				
	Ausführung	800 850 900	950 1000 1050	1100 1150 1200	1250 1300 1350
1000 1050 1100 1150 1200 1250 1300 1350 1400 1450	C 1001	✓	✓	✓	✓
	C 1002	✓	✓	✓	✓
	C 1004	✓	✓	✓	✓
	C 1005	✓	✓	✓	✓
	C 1006	✓	✓	✓	✓
	C 1016	✓	✓	✓	✓
	C 1017	✓	✓	✓	✓
	C 1070	✓	✓	✓	✓
	C 1071	✓	✓	✓	✓
	C 1072	✓	✓	✓	✓
	C VA55	✓	✓	✓	✓
C 10TT	✓	✓	✓	✓	
1500 1550 1600	C 1001	✓	✓	✓	✓
	C 1002	✓	✓	✓	✓
	C 1004	✓	✓	✓	✓
	C 1005	✓	✓	✓	✓
	C 1006	✓	✓	✓	✓
	C 1016	✓	✓	✓	✓
	C 1017	✓	✓	✓	✓
	C 1070	✓	✓	✓	✓
	C 1072	✓	✓	✓	✓
	C VA55	✓	✓	✓	✓
	C 10TT	✓	✓	✓	✓

Pforten System Classic (Sonderabmessungen)

Flügelhö- he (H) in [mm]	Abstand (Breite) zwischen den Pfosten (So) in [mm]				
	Ausführung	800 850 900	950 1000 1050	1100 1150 1200	1250 1300 1350
1650 1700 1750	C 1001	✓	✓	✓	✓
	C 1002	✓	✓	✓	✓
	C 1004	✓	✓	✓	✓
	C 1005	✓	✓	✓	✓
	C 1006	✓	✓	✓	✓
	C 1016	✓	✓	✓	✓
	C 1017	✓	✓	✓	✓
	C VA55	✓	✓	✓	✓
	C 10TT	✓	✓	✓	✓
1800 1850 1900 1950	C 1001	✓	✓	✓	✓
	C 1004	✓	✓	✓	✓
	C 1006	✓	✓	✓	✓
	C 1016	✓	✓	✓	✓
	C 1017	✓	✓	✓	✓
	C VA55	✓	✓	✓	✓
	C 10TT	✓	✓	✓	✓